

FIREPIT



HEAT[®]
DESIGN BY HENRIK PEDERSEN

OWNERS MANUAL:






USE OUTDOORS ONLY.

Read the manual before using the bbq.

WARNING:

Accessible parts may be very hot. Keep young children away.

DESIGN[®]
HOUSE **DENMARK**



ASSEMBLY INSTRUCTION:

Assemble the fireplace according to drawing.

When using the firepit for burning wood use the lower setting of wood basket.

When using the firepit as a bbq use the upper setting for wood basket.

Only use the fireplace on a plain surface.

WARNING:

Accessible parts may be very hot.

Keep young children away.

Use outdoors only.

Read the instructions before using the appliance.

ACHTUNG:

Teile des Gerätes können bei Gebrauch sehr heiss werden. Vorsicht mit Kindern.

Nur im Freien zu verwenden. Unbedingt Gebrauchsanleitung vor Inbetriebnahme beachten.

ADVARSEL:

De tilgængelige dele kan være meget varme.

Hold derfor små børn på afstand.

Må kun benyttes udendørs. Læs brugsvejledningen før brug.

OPGELET:

Onderdelen kunnen bij gebruik erg heet worden.

Kinderen op afstand houden.

Alleen voor gebruik buitenshuis. Lees de gebruiksaanwijzing alvorens het toestel te gebruiken.

ATTENTION!

Les pièces accessibles peuvent être très chaudes.

Tenez les enfants à distance.

N'utilisez l'appareil qu'à l'extérieur. Lisez les instructions attentivement avant l'utilisation.

ADVERTENCIA:

Las piezas accesibles pueden estar muy calientes.

Mantenga alejados a los niños pequeños.

Sólo para uso al aire libre.

Lea estas instrucciones antes de usar la barbacoa.